

iHome®

Model: iB40


Studio Monitor Style Stereo Headphones with In-Line Volume Control



Using Your iHome Headphones

The ear cups are marked "L" and "R". When worn properly the headphone cable with in-line volume control will be on your left side. The two ear cups may be adjusted up or down for most comfortable fit.

Connect the headphone plug to the headphone jack of your music player. Be sure that the plug is fully inserted into the jack. If the plug is not fully inserted you may only hear sound from one side of the headphones.



If you are using this headphone with an older stereo receiver that has a larger size headphone jack, attach the supplied 6.3mm headphone plug adapter to the 3.5mm headphone plug.



To protect your hearing, always start listening with the In-Line Volume Control set to a low level and gradually increase the volume to a comfortable listening level.

Note: You may have to adjust the volume control on your music player as well as the In-Line Volume Control on your headphones to find the most satisfactory sound level. If one control is set too low and the other is set too high, the sound may be distorted. Try setting the volume control on your music player halfway between the Min and Max settings, and then use the In-Line Volume Control on your iHome headphones to make final adjustments.

IMPORTANT! Listening at high volume for long periods of time can result in long-term hearing damage. For your safety, do not use headphones if they would prevent you from hearing warning sounds, such as while driving a car or motorcycle, riding a bike, etc. Remember that studio monitor style headphones such as the iB40 may block outside noise, including warning sounds. Always be aware of your surroundings and do not use these headphones in situations that require you to hear warning sounds.