


PI AYTOUGH

Waterproof Portable Speaker





BLUETOOTH PAIRING -

-Press & hold to enter pairing mode -Select 'iHome iBT154' on your device to connect

-To cancel pairing mode, press again



-RESET BUTTON

Use the extended tip of a paper clip or other thin tool to push in the reset button

CHARGING THE SPEAKER





LED STATUS INDICATORS

DATTEDV STATUS

DATTERT STATOS		
Θ,	RED	charging (slow blink)
•	OFF	fully charged
`oʻ	RED	low battery (fast flash)

BLUETOOTH STATUS

`o´	BLUE	pairing (flashing)
0	BLUE	connected to Bluetooth

WATERPROOF COVER

Before using near water, make sure the waterproof cover is completely flush with the unit. Press along the entire edge of the cover until it is securely in place.







For questions, full instructions, warranty, and additional safety information, please scan the QR code or visit; www.ihome.com/help/ibt154



FCC Information

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause

 Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause barmful interference to radio or

However, there is no guarantee that their receive will not occur in a particular instancion; it has equipment does cause narmon their reference to radio or

Regrient or relocate the receiving antenna.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 Consult the dealer or an experienced radio/TV technician for help.

CAN ICES, T (B) / NMB, T(B)

IC Statement

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain

Calculation from about the exposure and complete the property of the property of 20 cm between the radiator and your body. Cet équinement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnement non contrôlé

Cer equipment est continue aux inities d'exposition aux rainations à contre de l'exposition aux contre de l'entre de l'en économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) L'appareil ne doit pas produire de brouillage;

(1) Lapparein lei ours pas producte de urberussige; (2) L'appareil doit accepter tout brouillage radioelectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité et la conformité de l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité et la conformité de l'exposition de RSS-102 rf, Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corns

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment Tout changement ou modification non expressement approuve par la partie responsable de la conformité pourrait annuler le droit de l'utilisateur à utiliser l'équinement

WARNING/DISPOSAL OF UNIT

Do NOT attempt to change the battery. Doing so will void the warranty and could cause injury and damage to your device. To Never dispose of used batteries/electronics with ordinary solid wastes, since they contain toxic substances.

Always dispose of used batteries/electronics in accordance with the prevailing community regulations.
 Many electronics retailers now recycle batteries and other electronic components at no charge

GENERAL BATTERY PRECAUTIONS

· Never use or charge a battery if it appears to be leaking, discolored, deformed, or in any way abnormal. Never disassemble the unit or attempt to remove battery as that could cause leakage of alkaline solution or other electrolytic

Avoid charging a rechargeable battery when the temperature is not within 5°C - 35° C (41° - 95° Fahrenheit).

Never expose a battery to any liquid

 Never expose a battery to excessive heat such as direct sunlight or fire. Never use a battery pack in an unventilated vehicle where excessive internal temperatures may be encountered.
 Always keep batteries out of the reach of infants and small children. IMPORTANT SAFFTY INSTRUCTIONS

Please heed all warnings, read and follow all instructions and keep these instructions handy for future reference.

Clean only with dry cloth. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.

Heat - This product should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat. Only use attachments/accessories specified by the manufacturer.

Unplug this product during lightning storms or when unused for long periods of time.

Damage Requiring Service - This product should be serviced by qualified service personnel when: Objects have fallen into or liquid has been spilled into the enclosure

The unit has been exposed to rain. The unit has been dropped or the enclosure damaged.

The unit exhibits a marked change in performance or does not operate normally No naked flame sources, such as lighted candles, should be placed on this product.

This product is suitable for use in tropical and/or moderate climates.

Do not dispose of batteries in the household trash or fire. CAUTION - Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type If the unit is to be unused for an extended period of time, such as a month or longer, charge the unit fully before storage. 13 Always use a UL/ETL certified charging adapter (not included), and the supplied USB charging cable.



© 2020 SDI Technologies, Inc. All rights reserved