











For warranty visit www.home.com/support

Snooze/Display Dimmer

1. To program Snooze, press and hold the Snooze/Display Dimmer during normal operation (selent no salem is sounding).

2. Press the \* or \* Suttons to select the desired annoze time (between 01 and 20 minutes).

Quick Start Guide

- Press and release the Snooze/Display Dimmer Button to confirm Snooze setting, 2 beeps will sound.
- While the alarm is sounding, press and release the Snooze/Display Dimmer Button to temporarily silence the alarm for the set duration (9 minutes is the default). Snooze can be used several times during the 1 hour alarm sounding time.
- . To adjust the brightness of the display, press and release the Snooze/Display Dimmer Button during normal operation (when no alarm is sounding) to cycle through the brightness display settings (H; 3, 2, Lo, and Off).

- Manual Bluetooth Pairing

  1. Press and hold the Bluetooth Button on the back of the iBTW390 for 2 second: "PAIR" will appear on the display and the Bluetooth indicator will fliash blue.
- Select 'Home (BTW300' on your device's Bluetooth menu to connect device. If pairing is successful, a voice prompt will announce 'CONNECTED' and the Bluetooth indicator will appear sold blue, indicating the (BTW300 is ready to play audio.
- Once the IBTW300 is paired to a device, it will attempt to autolink when the device is within range (about 33 feet). To reset Bluetooth, press and hold the **Bluetooth Buttor** for 10 seconds.

## Playing Audio Via Bluetooth

- Praying Audio V or Ballection:

  1. "bit" and the \$ \$\frac{8}{3}\text{tistooth} indicator appear on the display when the unit is on and your derive is connected. Press the | \* Button on the unit to play or pause audio from your linked Bustooth derives.

  2. Press the = \circ + \frac{8}{3}\text{tistooth} is adjust the volume on the unit.

- The unit must be powered on and Irrised to a Blustooth phone to receive a a. 

  1. When a cell is received, playing music is musted to hear the ring tone. 

  "Call" will fill an to the display. 

  Dress the Button to aresser the call. 

  Press and hold "is Button to given the call. 

  2. Press the b Button to give the call and resume previous function.

## Using Voice Control

NOTE: The unit must be powered on and Inked to an iOS or Android Skuetoo use Voice Control, Press and hold the P Button for 2 seconds. "CALL" will ap display. Wait for a beep to activate voice control with Siri or Google Assistant.

- Connect the standard size end of a USB cable (not included) to the USB port on the back of the unit and connect the other end to the charging port on your device.
- Monitor the changing on your device.
   Some devices use a proprietary changing method and will not change using the USB port. If this happens, you must change your device using the changer that came with it.





# Battery Back-Up

- Remove the exhausted battery from the compartment and insert I CR-2450 battery, checking that the + side is facing you. Replace the compartment door, Do not overtighten.

## WARNING A

On ordings the battery, Chemical Burn Hazard This product contains a coin/button cell
and the product of the contains a coin/button cell
and Torour and one last for data.

Keep one and used batteries may from children if the battery compartment does not
close securely, stops upon the product and super a pasy from children if the battery compartment does not
close securely, stops upon the product and super a pasy from children if you brint
batteries might have been swillowed or placed raide any part of the body, seek immediate
an medical atterior.

- IMPORTANT SAFETY INSTRUCTIONS

  These and not to design the carry, trained in their designed of appropriate in surprise, other appropriate in the carry of a principle in the carry of the carry of a principle in the carry of the carry of a principle in the carry of the carry of a principle in the carry of the carry of

 Convact the desire or an experienced radio/TV technician for help.

CAN ICER-18(6) / NMR-18(6)
CAN ICER-18(6) / NMR-18(6)
ICE SESSENCE
This desire contained representation ratios (Sessence) that comply with remotion, for the contained representation repres This device may not class introduces. 2 This device must brough any interference, nuclearly interference in cultural productions of production of the device.

Local Conference of the device.

Local

The sequence during its effect of a sequence in the sequence of the sequence in the sequence of the sequence in the sequence of the sequence in the sequence in the sequence in the sequence is sequence in the sequence in the sequence is sequence in the sequence in the sequence in the sequence in the sequence is sequence in the sequence in the sequence in the sequence in the sequence is sequence in the sequence in the sequence is sequence in the sequence in the sequence in the sequence is sequence in the sequence in the sequence is sequence in the sequence in the sequence is sequence i

"Bit of the PCC Naise. There should be provide misconable protection against harmful interference in a residential installation. The first limit of the provide misconable installation. The first limit of the provided misconable installation. The first limit of the provided misconable installation. The provided misconable installation from the propriet discussed and the provided misconable in the provided misconable installation from the provided misconable installation from the installation from the provi

g antenna.

I the equipment and receiver,
outlet on a circuit different from that to
noed siddo/TV technician for help.

# # 2019 SDI Technologies, inc. All rights reserved. Guestions? Visit www.homs.com or call 1-800-288-2792 Toll Free

FCC Information

Model: iBTW390