


iH80 Extension Speaker Operation Instructions



Congratulations on your purchase of the iH80 extension speaker, allowing you to enjoy great stereo sound with your iH80.

Setup and operation is quite simple.

- 1) Make sure your iH80 is OFF.
- 2) Plug one end of the provided audio cable into the Ext. speaker jack on back of the iH80. Turn the Extension Speaker power switch to the ON position to enable speaker operation
- 3) Plug the other end of the audio cable into the jack on the back of the iH80 Extension Speaker. Place the two speakers as far away as practical for best stereo separation.
- 4) Press the Power ON button on the iH80. Adjust speakers as needed for best sound.



Please see your iH80 instruction book for warranty and maintenance information