

USING THE SANITIZER This superior quality UV-C LED light safely kills up to 99.9% of surface germs in under 3 minutes, without using

The iUV3 is safe to use on everyday essentials including eveglasses, smartphones, cosmetic tools, toothbrushes,

USING THE UV BRACKETS

Brackets are provided to ensure ontimal spacing between your objects and the LIVC LEDs. Swing brackets to a



· Place the unit on a level surface away from sources

- Remove the plastic protective film from the clock
- display natural wood and lacquered finish. A cloth or other protective material should be placed between it
- Should the casing of your device become soiled. you may wine down with a moist cloth
- Do not immerse the device into water or any Do NOT use gasoline, benzene, thinner, harsh
- as they may damage the product. NEVER use

1. Make sure the iUV3 is plugged into a working wall outlet

SANITIZING ITEMS

- place items inside making sure not to overlap items
- Press and release the Sanitize Button
 to begin a UV sanitizing cycle. A countdown timer will display the remaining cycle time, the Sanitize status indicator will appear on the display, and a beep will sound when the cucle is complete
- To extend to the current cleaning cycle, press and release the Sanitize Button again. Each press adds 180 seconds to the cycle, with a maximum cleaning time of 900 seconds. When the cleaning cycle is over, 'End' will annear on the clock display for 2 seconds, and then the



NOTES Features a built-in safety switch that will shut off the UV light whenever the lid is opened. Do not attempt to

2. If the lid is opened during the UV sanitizing cycle, the timer will pause. Closing the lid within 1 minute will

resume the cycle. 3. We recommend leaving the brackets in place while may be removed. In those cases we recommend

antimal offect To cancel a sanitizing cycle, press and hold the Sanitize Button for 2 seconds. The clock time will appear on the

WARNING - To reduce the risk of fire or electric shock, do not expose this product to

ATTENTION: Use only the supplied power adapter. This product must only be supplied at safety extra low voltage corresponding to the marking on the

The mains plug of power adaptor is used as the disconnect device, it shall remain

ATTENTION: Prolonged or excessive exposure to UV-C light may degrade and riscoving falleting placeting and other non-matality materials.

freezing. Do not operate/drop near water or while bathing or swimming, do not handle the device with wat hands.

or devices. Do not use device for other than its intended purpose, as described in the

names. To not operate if any damage to the unit is visible or suspected, such as after

Keep the cable/cords and device away from heated surfaces.

Close supervision is necessary when any appliance device is used by or near children and people with special needs.

Do not operate in the presence of explosives and/or flammable furnes, smoke

Unplug unit and clean only with damp cloth. Stronger cleaning agents, such as Benzame, thinner or similar materials can damage the surface of the unit. Heat - This product should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that

ë. Mana Barkirina Sanina ... This renykyt should he saninad hy akalifiad

normally.

No naked flame sources, such as lighted candles, should be placed on this

product.
Attention should be drawn to the environmental aspects of battery disposal.
This remainst is suitable for use in territoral analyse moderate climates."

Disclaimer: This product is not intended to diagnose, treat, cure or prevent any disease or medical condition. The information provided herein is not to be construed as a medical diseases or medical advice. No medical claims are incolled

© 2021 SDI Technologies, Inc. All rights reserved. Questions? Visit www.ihome.com

iquids. not use this product near water.

CLOCK SETUP Step One: Connecting the Unit

> working wall outlet not controlled by a light switch. 9

> the back of the unit and connect the other end to a

Step Two: Setting Your Clock

. Press and hold the Time Set Button (on the back of the unit) for 2 seconds until the clock displa flashes and a been sounds. Release the Time Set Dutton 2. Press the - or + Buttons to adjust the clock to the current time (hold for rapid setting). Make sure you

appears to the left of the display. (There is no AM 3 Dress and release the Time Set Button to confirm the current time setting. The YEAR will flash on the

display. Press the - or + Buttons to set the year. Press and release the Time Set Button to confirm the current year setting. The month will flash on the 5. Press and release the Time Set Button to confirm

the current month setting. The day will flash on the display. Press the - or + Buttons to set the day. 6. Press and release the Time Set Button to confirm settings. 2 beeps will sound to indicate time setting

Daylight Savings Time: By default, the DST Switch is set to Auto and will automatically adjust the time in March/November.

Tip: Press the Alarm Button during clock setting

to toggle between 12/24 hour display modes

SETTING THE ALARM

1. Press and hold the Alarm Button for 2 seconds until the display flashes. A beep sounds. Release the Alarm Button 2. Press the - or + Buttons to adjust the alarm time to

Quick Start Guide

QUESTIONS? visit www.ihome.com

- the desired time (hold for rapid setting). Make sure you set the correct AM/PM alarm time. The PM indicator appears to the left of the display. (There is no AM indicator)
- 3. Press the Alarm Button to confirm the alarm time setting. The alarm schedule will flash: 7 (every day). 5 (weekdays) or 2 (weekend only) Press the - or +
- Buttons to select an alarm schedule Press the Alarm Button to confirm the alarm settings and exit alarm setting mode. 2 beeps will confirm alarm setting is complete. The alarm icon will remain on the display, to show the alarm is armed.
- To Preview: Press and release the Alarm Button to

Turning Alarm ON/OFF: Press and release the Alarm Button twice within 5 seconds to toggle the alarm ON and OFF, indicated by the related white alarm

When the alarm sounds, press the Alarm Button to

disable the alarm and reset it to come on at the same

SNOOZE / DISPLAY DIMMER

Snooze: When the alarm is sounding, press the ZZZ/Dimmer Button to snooze for 9 minutes Dimmer: Press the ZZZ/Dimmer Button (when alarm (Display can be dimmed during Snooze mode.)

To adjust the snooze duration 1. Press and hold the ZZZ/Dimmer Button.

2. Healthalt or - Buttone to adjust the enouge duration from 1-29 minutes. Press the 777/Dimmer **Button** again to confirm CHARGING DEVICES VIA USB

There is a 1A USB charging port on the iUV3. To

PROGRAMMABLE SNOOZE

charge your device connect a standard USB cable (not included) to the USB port on the unit, and plug the other end into the charging port on your device Note: Unit must be plugged into a working outlet

in order to charge devices.

Battery Back-Up The unit comes with a CR-2450 back-up battery

installed to provide continuous alarm operation and clock settings in the event of a temporary power failure. Remove the battery pull tab before use. When the battery icon on the clock display is flashing, it is time to replace the back-up battery. The battery

 Make sure the ∆C adapter is connected, or you will lose your time and alarm settings during 2. Use a Phillips screwdriver to open the battery compartment door. 3 Damous exhausted hattery from

Č ... compartment and insert new 1 CR-2450 battery, checking that the side is facing you. Replace compartment door. Do not overtighten.

If you are experiencing abnormal operation, try to

(4)

BACKUP

Disconnect the AC adapter and remove the backup unit. Wait 2 minutes, then re-install the battery and

WARNING $\wedge \oplus$ This product contains a buttory/coin cell battery. Do not ingest the

Into produce command a distorycoln our partney, too not inpute, to battery, Chemical Born Hazdraff, if the button/coin cell battery is swallowed or placed inside any part of the body, it can cluste severe or fall internal chemical burn injuries in 2 hours or less. If you thrist batteries might have been swallowed or placed inside any part of the body, seek inmediate medical attention.

Maintenance + Caring For Your Device

Please heed all warnings, read and follow all instructions and keep these instructions handy for future reference.

LID/TOP OPEN. The device was designed to shut off automatically when the lig/top is open. It is important NOT to defeat or tamper with this safety feature as UVC lorfs can cause demand to execute the defeat.

WARNING - KEEP OUT OF REACH OF CHILDREN. This device is not a toy and is not

no charge. To find a drop-off location near you, visit

product and keep it away from children. CAUTION - RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE, DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

Place the unit on a level surface away from sources of dir

Do not immerse the device into water or any cleaning solvents.

IMPORTANT SAFFTY INSTRUCTIONS

WARNING - DO NOT ATTEMPT TO OPERATE THIS DEVICE WITH THE

or intended with the sale of this device. Purchaser accepts responsibility for correct and proper use of device. All users should be alerted to the potential treasures seeme.

Belling on the user and these resourcions.

WARNING - Use this device only for its intended use as described in this manual. If the device is not used in the manual reposition, they protection provided by the equipment may be compromised. Always place device on a flat, smooth surface, using the repositional use. 1 Year Limited Warranty For warranty and full instructions, visit ihome com/support

ECC Information This equipment compiles with FCC RF radiation exposure limits set forth for an incontrolled environment.

can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

ISED information

This equipment complies with IC RSS-102 radiation exposure limits set forth for an

Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies.

(i) L'appareil ne doit pas produire de crousage; (2) L'appareil de da cepter tout brouillage adoléschique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. L'appareil est conforme aux exigences d'exposition RF DED, les utilisateurs peuvent obterir des informations canadiennes sur l'exposition aux RP et la conformità. Cet dequipment doit ôthe installe et utilise avec une distance minimisé de 20 cm entre.

Printed in China

IUV3-QSG-031121-A