

Model: IWST26  
Instruction manual - US English  
Size: 102 x 150 mm  
Date: July 16, 2021  
Mat: 157gsm Art paper  
Color: Black colour



iHome

SHIATSU MASSAGE LOUNGER

Deep Tissue Back Massager with Heat

iWST26

Quick Start Guide

CAUTION:  
PLEASE READ ALL INSTRUCTIONS BEFORE USING

What's Included:

LED on adapter will glow solid green when connected to power

Getting Started

- Place the unit on a sofa or chair with a backrest.
- Connect the plug to a wall outlet not controlled by a light switch.

2-blade polarized AC plug:

To reduce the risk of electric shock, this appliance has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way.

Power ON/OFF

Press the **POWER BUTTON** to turn the massager on. The Power Indicator will light up on the control pad. Press again to turn the unit off. The Power indicator will turn off.

Auto Shut-Off

Note: The unit will automatically shut off after 15 minutes of use. Turn the unit ON again to resume operation. Always unplug the AC power cable after use.

1

How to Use

SPOT MESSAGE (NECK)

Press and hold the **UP ARROW BUTTON** to move the neck massager up to the desired position. Release the button to stop. Press and hold the **DOWN ARROW BUTTON** to move the neck massager down to the desired position. Release button to stop.

MANUAL KNEADING

Press the **MANUAL KNEADING BUTTON** once to start a kneading neck massage in a clockwise direction (the indicator light will turn on solid red). Press again to change to a counter-clockwise direction (indicator light will blink slowly). Press again to stop kneading.

AUTO KNEADING

Press the **AUTO KNEADING BUTTON** once to start a kneading neck massage in a clockwise direction (the indicator light will turn on solid red). The massage nodes will automatically change direction every 15-30 seconds. Press again to stop (indicator light will shut off).

SHIATSU MESSAGE (FULL/UPPER/LOWER)

Choose from 3 pre-set massage zones: Full, Upper, or Lower. The massage nodes will focus on your selected zone and the corresponding indicator light will blink slowly. Press again to stop kneading.

LOCATE SPOT MESSAGE (BACK)

When the Shiatsu Massage Mode is active, press the **LOCATE BUTTON** to start or stop a spot massage. Use the **Locate Arrows** (up or down) to move the spot massage to your desired location.

HEAT THERAPY

Press the **HEAT BUTTON** once to start heat therapy (the indicator light will turn on and the massage nodes will turn red). Press again to turn off heat (indicator light will shut off).

SEAT VIBRATION

Choose from 3 levels of intensity: Low, Medium, or High. Press the **SEAT BUTTON** once to set to Low. Press again to change to Medium, and press once more to set to High. Press a fourth time to turn off.

2

Controls + Indicators

3

MAINTENANCE

- Unplug the unit before cleaning.
- Do not use steel wool, any liquid chemical cleansers, which could be abrasive or corrosive liquids (such as gasoline, acetone, or alcohol) to clean the product.
- Spot clean only. Wipe the cushion, control pad, and power cord only with a dry cloth. Do not use a damp cloth or detergent.
- When not in use, unplug the power cord and store the unit in a cool, dry place away from sunlight. Do not place heavy objects on top of the unit during storage.
- Do not open the zipper. The product has no user serviceable parts.
- NOTE: Not recommended for use on a wooden chair or surface as the zipper could damage the wood.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical products, especially when children are present, safety precautions must always be followed:

**READ ALL INSTRUCTIONS PRIOR TO USE.**

**DANGER - TO REDUCE THE RISK OF ELECTRICAL SHOCK:**

- ALWAYS UNPLUG THIS PRODUCT FROM THE ELECTRICAL OUTLET AFTER USE AND BEFORE CLEANING.

**WARNING - TO REDUCE THE RISK OF BURNS, FIRE, ELECTRIC SHOCK OR PERSONAL INJURY:**

- Never drop or insert any object into any opening.
- Unplug unit and clean only with dry cloth. Stronger cleaning agents, such as Benzene, thinner or similar materials can damage the surface of the unit.
- The main plug of power adaptor is used as the disconnect device, it shall remain readily operable.
- Stop using immediately and seek medical attention if you experience any abnormal or severe pain.
- This device should **NEVER** be left unattended when plugged in. Always unplug when not in use and before removing and replacing any of the attachments.
- Close Adult supervision is required when this device is in use by or on near children and disabled or persons with special needs.
- Use this device only for its intended purpose as described in these instructions.
- DO NOT operate this device if the cord or plug is damaged or frayed, has been dropped, damaged, or dropped into water or is not working properly. Inspect periodically for any signs of damage. If damage is found, DO NOT USE. Return the device to a service center for examination and repair.

- Keep the cord away from any sources of heat that could damage the cord's insulation. Such as stoves, radiators, heat registers, or other appliances that produce heat.
- DO NOT operate where aerosol products are in use or where oxygen is being administered.
- DO NOT block or inhibit the proper ventilation of the device by using it under a blanket, pillow. Overheating can occur and can cause personal injury, including fire or electric shock.
- ALWAYS keep the ventilation openings free of hair, lint, dust and other debris.
- ALWAYS keep long hair away from the device while in use.
- DO NOT use near loose clothing or jewelry.
- To disconnect, turn all controls to the off position, then remove plug from outlet.
- For Indoor Use Only DO NOT use outdoors.
- Use heated surfaces carefully. May cause serious burns. Do not use over insensitive skin areas or in the presence of poor circulation. The unattended use of heat by children or incapacitated persons may be dangerous.
- This device is designed for personal, household, nonprofessional use only.
- Only gentle body force should be placed against the device to eliminate risk of injury. Do not lean on the massage mechanism when adjusting your body position.
- Always wear clothing when using. Do not use on bare skin to avoid possible irritation.
- To avoid injury, do not insert your finger into the massage node during operation.

CAUTION: IF YOU ARE PREGNANT OR HAVE AN ILLNESS, PLEASE CONSULT WITH YOUR DOCTOR BEFORE USING THIS DEVICE.

PLEASE READ ALL THE INSTRUCTIONS CAREFULLY PRIOR TO USE.

Consult with your doctor before use, if:

- You are pregnant.
- You have a pacemaker.
- You have an illness or otherwise have concerns regarding your health.
- NOT recommended for use by people with diabetes.
- NEVER leave the device unattended and plugged in around children.
- DO NOT use this device for more than 20 minutes at a time.
- NEVER use this device directly on swollen, inflamed or open skin wounds, joints of elbows and knees, breasts or abdomen.

THIS DEVICE IS NOT A SUBSTITUTE FOR MEDICAL ATTENTION.

SAVE THESE INSTRUCTIONS

4

FCC Information

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.  
This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.  
• Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.  
• NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.  
These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
• Reorient or relocate the receiving antenna.  
• Increase the separation between the equipment and receiver.  
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
• Consult the dealer or an experienced radio/TV technician for help.

ISED Information

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.  
This device complies with ICES-001 (Exempt Transmitter) and ICES-002 (Exempt Receiver) of the Canadian Radio-television and Telecommunications Commission (CRTC).  
(1) This device may not cause interference.  
(2) This device must accept any interference, including interference that may cause undesired operation of the device.  
The device complies with SED RF exposure requirement, users can obtain Canadian Information on RF exposure and compliance.  
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.  
Cet équipement est conforme aux limites d'exposition aux radiations IC RSS-102 établies pour un environnement non contrôlé.  
L'émetteur/récepteur exempt de licence conforme dans le présent appareil est conforme aux CNR d'Innovation, Science et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:  
(1) L'appareil ne doit pas produire de brouillage.  
(2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.  
L'appareil est conforme aux exigences d'exposition RF ISED, les utilisateurs peuvent obtenir des informations canadiennes sur l'exposition aux RF et la conformité.  
Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.  
Tout changement ou modification non expressément approuvé par la partie responsable de la conformité peut annuler l'autorisation de l'utilisateur d'utiliser l'équipement.  
CAUTIONS (B / NIS-102)

5

Limited One Year Warranty

iHome Products, a division of SDI Technologies Inc. (hereafter referred to as SDI), warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for a period of one (1) year from the date of original purchase.

Should this product fail to function in a satisfactory manner, it is best to first return it to the store where it was originally purchased. Should this fail to resolve the matter and service still be required by reason of any defect or malfunction during the warranty period, SDI will repair or, at its discretion, replace this product without charge. This decision is subject to verification of the defect or malfunction upon delivery of this product to the Factory Service Center authorized by Customer Service.

If service is required, please contact Customer Service at [home.com/support](mailto:home.com/support) to obtain a Return Authorization Number and shipping instructions. A copy of the sales receipt is required to validate in-warranty coverage.

**Disclaimer of Warranty**

NOTE: This warranty is valid only if the product is used for the purpose for which it was designed. It does not cover (i) products which have been damaged by negligence or willful actions, misuse or accident, or which have been modified or repaired by unauthorized persons; (ii) cracked or broken cabinets, or units damaged by excessive heat; (iii) damage to digital media players, CD's or tape cassettes (if applicable); (iv) the cost of shipping this product to the Factory Service Center and its return to the owner.

This warranty is valid only in the United States of America and does not extend to owners of the product other than to the original purchaser. In no event will SDI or any of its affiliates, contractors, resellers, their officers, directors, shareholders, members or agents be liable to you or any third party for any consequential or incidental damages, any lost profits, actual, exemplary or punitive damages. (Some states do not allow limitations on implied warranties or exclusion of consequential damages, so these restrictions may not apply to you.) This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Your acknowledgment and agreement to fully and completely abide by the above mentioned disclaimer of warranty is contractually binding to you upon your transfer of currency (money order, cashiers check, or credit card) for purchase of your SDI product.

© 2021 SDI Technologies, Inc. All rights reserved.  
Questions? Visit [www.ihome.com](http://www.ihome.com)

IKWS26-0102-1-A

Printed in China

6