iHome + MELODY
PERSONAL MUSIC ASSISTANT

VOICE CONTROL WITH iB71

Press ⌢ once for voice request, then speak after the beep

More tips:
- When music is playing, pressing ⌢ will pause music. To resume music simply press ⌢
- To trigger a voice request while music is playing: Double-click ⌢ then speak after the beep