




Model: iB19

behind-the-neck fitness headphones with in-line mic+remote

Cord Management


The hang tag at the top of the package also functions as a convenient cord management device. Pass the headphone's plug through the opening in the hang tag as shown and then wind the headphone cord around the hang tag. This will keep your headphones cord tangle free and always ready to use.



Using Your iHome Behind-the-Neck Fitness Headphones

The iHome iB19 headphones provide a secure fit to stay in place during moderate to strenuous physical activity thanks to the behind-the-neck wearing position and the additional hooks that fit around your ears and keep the speakers positioned properly against the outside of your ears.

To put the headphones on, use two hands to position the headphones behind your head as shown, with the flat cable on your left side. Then place the headphones over your ears with the color coordinated hooks resting between your head and ears and the speakers resting against the outside of your ears. If your hair is shoulder-length or longer you can choose to wear the headphones with the neckband outside of your hair or under your hair, whichever is more comfortable for you.



Connect the headphone plug to the headphone jack of your phone or music player and make sure that the plug is fully inserted into the jack. If the plug is not fully inserted you may only hear music from one speaker and/or some of the telephone control functions may not work properly.

Always start listening with the volume control of your phone or music player set to a low level and then gradually increase the volume control to a comfortable listening level. Keep in mind that volume level of different tracks can vary widely, and that even within the same track there can be wide variations between loud and soft passages.


In-Line Control with Microphone

Model iB19 includes an in-line, one-button controller that allows you to answer and end phone calls 'hands-free'. You may also be able to record voice memos and control the music playback if your specific phone model provides for control of those features through the headphone jack.

NOTE: Not all of the hands free functions are available on all phones. You may find that some functions may work with your phone while others do not. This is due to the design of your specific phone and is not an indication of any problem with the iB19 headphones.

Answer / End Calls

When an incoming call is received briefly press the controller button once to answer the call and speak into the microphone. To end the call, briefly press the controller button again.



Music Playback Control

If your phone or music player provides for this feature through its headphone jack press the controller button once to begin playback and once again to pause playback. Press the controller button twice to skip to the next track, or three times to skip back to the previous track.

Voice Memo Recording

If your phone or music player provides for this feature through its headphone jack, place your phone in the Voice Memo Recording mode, then press the controller button briefly to begin voice recording and speak into the microphone. Press again to end the recording. Note: To listen to your voice memo recording you must use the controls on your phone. You cannot access recorded voice memos from the iB19 in-line controller.

IMPORTANT! Listening at high volume for long periods of time can result in long-term hearing damage. For your safety, do not use headphones if they would prevent you from hearing warning sounds, such as while driving a car or motorcycle, riding a bike, etc. Remember that headphones such as the iB19 are very effective in blocking outside noise, including warning sounds. Always be aware of your surroundings and do not use these headphones in situations that require you to hear warning sounds.

Limited Lifetime Warranty Information

iHome Products, a division of SDI Technologies Inc. (hereafter referred to as SDI), warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for the lifetime of the product from the date of original purchase.

Should this product fail to function in a satisfactory manner, it is best to first return it to the store where it was originally purchased. Should this fail to resolve the matter and service still be required by reason of any defect or malfunction during the warranty period, SDI will repair or, at its discretion, replace this product without charge. This decision is subject to verification of the defect or malfunction upon delivery of this product to the Factory Service Center authorized by SDI Customer Service. The product must include proof of purchase, including date of purchase. An out-of-warranty fee for service will be charged for units that are received without proof of purchase.

Before returning this product for service, please first replace the batteries (if applicable) with fresh ones, as exhausted or defective batteries are the most common cause of problems encountered. If service is still required:

1. Call SDI Customer Service at 1-800-288-2792 for Return Authorization and for the address of the Factory Service Center.
2. Remove the batteries (if applicable) and pack the unit in a well padded, heavy corrugated box. SDI is not responsible for damage that occurs during shipping to the Factory Service Center.
3. Enclose a photocopy of your sales receipt, credit card statement, or other proof of the date of purchase, if within the warranty period. Also include your name and address information, a brief description for why the unit is being returned, and the return authorization number. No unit can be processed without a return authorization number.
4. Write the return authorization number on the side of the shipping package and send the unit prepaid and insured to the Factory Service Center address authorized by SDI Customer Service.

Disclaimer of Warranty

NOTE: This warranty is valid only if the product is used for the purpose for which it was designed. It does not cover (i) products which have been damaged by negligence or willful actions, misuse or accident, or which have been modified or repaired by unauthorized persons; (ii) cracked or broken cabinets, or units damaged by excessive heat; (iii) damage to digital media players, CD's or tape cassettes (if applicable); (iv) the cost of shipping this product to the Factory Service Center and its return to the owner.

This warranty is valid only in the United States of America and does not extend to owners of the product other than to the original purchaser. In no event will SDI or any of its affiliates, contractors, resellers, their officers, directors, shareholders, members or agents be liable to you or any third party for any consequential or incidental damages, any lost profits, actual, exemplary or punitive damages. (Some states do not allow limitations on implied warranties or exclusion of consequential damages, so these restrictions may not apply to you.) This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Your acknowledgement and agreement to fully and completely abide by the above mentioned disclaimer of warranty is contractually binding to you upon your transfer of currency (money order, cashier's check, or credit card) for purchase of your SDI product.

© 2014 SDI Technologies, Inc. All rights reserved.

**Questions? Visit www.ihome.com
or call 1-800-288-2792 Toll Free**