

iHome®

Model iD83 The Home System For Your iPad®

works with



iHome Sleep
alarm clock app



iHome Radio
internet radio app



Available on the
App Store



Note: *iHome Sleep* and *iHome Radio* apps are not covered in detail in this booklet. To learn more about how these apps can enhance your experience, please download the free iHome Sleep app from the App Store and review the Start Guide.

Questions? For latest instructions, visit www.ihomeaudio.com/support

Table of Contents

Controls and Indicators / Unit Display	1
Quick Start	2
Setting Up the unit	4
Using the unit	5
Installing/Replacing Clock Back-up Batteries / Battery Warning	8
A Consumer Guide to Product Safety	9
Troubleshooting	10
Warranty Information	12

A Consumer Guide to Product Safety

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with the limits for a Class B digital device as specified in Part 15 of FCC Rules. These limits provide reasonable protection against radio and TV interference in a residential area.

However, your equipment might cause TV or radio interference even when it is operating properly. To eliminate interference you can try one or more of the following corrective measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and the radio or TV.
- Use outlets on different electrical circuits for the equipment and the radio or TV.
- Consult your dealer or an experienced radio/television technician if the problem still exists.

Modifying or tampering with your system's internal components can cause a malfunction and might invalidate the system's warranty and void your FCC authorization to operate it.

This Class B digital apparatus complies with Canadian ICES-003.


Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Maintenance


- Place the unit on a level surface away from sources of direct sunlight or excessive heat.
- Protect your furniture when placing your unit on a natural wood and lacquered finish. A cloth or other protective material should be placed between it and the furniture.
- Clean your unit with a soft cloth moistened only with mild soap and water. Stronger cleaning agents, such as Benzene, thinner or similar materials can damage the surface of the unit.

Controls and Indicators


Top Panel



Rear Panel




Unit Display



NOTE: AM/PM indicators will not appear when clock is set to 24 hour display mode



quick start

1: power



Attach AC adaptor cable to DC jack on back of the unit and plug the other end into a wall socket.


2: docking your iPad/iPhone/iPod



Gently dock your iPad, iPhone or iPod into the 30 pin dock. If using an iPad with a cover or "skin", first remove the rubber dock pad on the unit. The iPad, iPhone or iPod will charge while docked. Press the ►|| Button on the unit to play your iPad, iPhone or iPod.

quick start

3: time sync



Dock your iPad, iPhone or iPod (see step 3). Press and release the **Time Sync Button** located on back of the unit. “TIME SYNC” will appear on the display, followed by “TIME UPDATED” upon successful syncing.

4: radio



Press the **Mode Button** as needed to select FM band.
Press the **+** or **- Button** to tune in a station.
See page 7 for programming presets.

Updating your iD83 firmware

For best performance, make sure to update the unit's firmware. To do so, download the free iHome Sleep app from the App Store. Launch the app, then go to Settings/iD83 and follow directions to update the firmware.

Connect unit to Power Source

Plug the AC adaptor cable into the AC Adaptor Jack and the other end into a standard 120V AC wall socket. Adaptor must be plugged in to operate unit. **The unit does not operate on batteries** (a battery back up system maintains clock settings during power failures).

Setting the Time Zone

This unit is a preset clock: the clock is preset at the factory. It's simple to match the Time Zone setting to your location (US only).

1. Depending on your location and whether or not Daylight Saving Time (DST) is in effect, manually set the **DST Switch** located at the back of the unit to +1 to add an hour or to -1 to subtract an hour.
2. Press and hold the **Time Zone Button** located on the back of the unit until the Time Zone flashes on the lower part of the display. Press the **+** or **- Button** to select your time zone. **Note:** Time Zone is disabled when clock display format is set to 24 hours.
3. Press the **Time Zone Button** again (or no button within 10 seconds) to exit the time zone setting mode.
4. If the displayed time is not correct, please see Setting Time and Calendar Manually below.

Setting Time Using iPad/iPhone/iPod Time Sync

The Time Sync feature allows you to sync the time setting on the unit to the time from your iPhone, iPad or recent model iPod (iPod touch, iPod nano and iPod Classic; older iPod models such as iPod mini do not support this feature).

1. Press the **Time Sync Button** located at the back of the unit, "Time Sync" flashes on the lower part of the display.
2. Once sync is completed, "Time Updated" will appear on the display.
3. If sync was not successful, "Sync Failed" will appear on the display. If this happens, please try again, with a different iPad/iPhone/iPod if needed. If sync still fails, please see Setting Time and Calendar Manually (below).

NOTE: iPhone time is automatically updated to the correct time via cell phone towers. The time on your iPad or iPod is accurate only to the time on the computer the last time the iPad/iPod was synced to it. It's possible to have up to 59 seconds difference between the iD85 and synced iPhone/iPod.

Setting Time and Calendar manually

1. Press and hold the **Time Set Button** located at the back of the unit until the time flashes on the display.
2. Press the **+** or **- Button** to set the correct time (hold for faster setting). Remember to set the correct AM or PM time. The **AM/PM Indicators** appear to the left of the time display.
3. Press the **Time Set Button** again. The year will flash. Press the **+** or **- Button** until the current year is displayed.
4. Press the **Time Set Button** again. The month and date will flash. Press the **+** or **- Button** until the current month/date is displayed.
5. If desired, press either the **12** or **24** button during Time set to toggle the clock display format to 12 hours or 24 hours.
6. Press the **Time Set Button** again (or no button within 10 seconds) to exit the time/calendar setting mode.

NOTE: You can also adjust settings on the unit via the iHome Sleep app. To do so, press and hold the **⏻ Button** when the iHome Sleep app is open and in view. See the iHome Sleep Start Guide for more information.

Using the Alarms

This unit has a dual alarm system so you can set two separate alarms to different alarm times, wake-to sources and frequencies (daily, weekdays or weekend). *Tip: Download the free iHome Sleep app for advanced alarm, snooze and sleep functions*

Setting the Alarms

1. Press and hold the **1** or **2** **Button** until the alarm time flashes on the lower part of the display. Press the **+** or **- Button** to set the alarm time (hold for faster setting). Remember to set the correct AM or PM time.
2. Press the **Alarm Button** again to confirm the set alarm time, then press the **+** or **- Button** to set the alarm frequency (7 = the whole week, weekday = Monday through Friday, weekend = Saturday and Sunday only).
3. Press the **Alarm Button** again, then press the **+** or **- Button** to select an alarm source to wake to: (iPod, Radio, Buzzer, Playlist or App).

For wake to iPod: select iPod to wake to a docked iPad, iPhone or iPod. If the unit does not detect an iPad/iPhone/iPod at the set alarm time, the unit will default to buzzer alarm. The alarm cycle lasts for one hour; make sure you have enough music on your iPad, iPhone or iPod to last that long.

For wake to radio: after selecting Radio as wake to source, press the **Alarm Button** and then press the **+** or **- Button** to select AM or FM band. Press the **Alarm Button** again and press the **+** or **- Button** to select a radio station or press the **Preset Button** to wake to a preset radio station (see *Using Radio* on page 6 for details on setting radio stations and presets).

For wake to playlist: you must create a playlist named “iHome” in iTunes and have it on your iPod/iPhone. The unit will play music randomly from within the “iHome” playlist. NOTE: you cannot wake to a playlist on your iPad.

For wake to app: you must have the free iHome+Sleep app installed and running on your iPad, iPhone or iPod to set custom app alarms.

4. Press the **Alarm Button** again, then press the **+** or **- Button** to set the alarm volume.
5. Press the **Alarm button** again (or no button within 10 seconds) to exit the alarm setting mode. The alarm will be armed once set and the corresponding alarm icon will light up. The lower part of the display will show the earliest set alarm time.

Reviewing, Arming and Disarming Alarm (Turn Alarm Function On and Off)

Alarms are automatically armed when set. Active alarms are indicated by alarm icons on the display.

1. Once an alarm is armed, the lower part of the display will show the alarm time. If more than one alarm is armed, the earliest alarm time will show.
2. To review the alarm time, press an alarm button once. The related alarm time will show on the lower part of the display.
3. During alarm review, press the alarm button once to toggle it on or off. If the alarm is armed, the related alarm icon will light up.

Resetting the Alarm to Come on the Next Day

1. When the alarm is sounding, press the **⏻ Button** to stop the alarm and reset it to come on the next set day. For example, if alarm is set for weekdays and you press the alarm reset on Friday, the alarm will come on again on Monday, not Saturday.

*TIP: When the iHome Sleep app is running, press the **wakeup button** to access wake profiles. When the app is not running, you can press the wakeup button to shut off the unit and reset the alarm to come on at the set time.*

Snooze Operation

1. To program a custom snooze time, press and hold the **Snooze Button** during normal operation (when alarm is not sounding) until the snooze minutes display appears. Press the **+** or **- Button** to set the snooze timer from 1 to 29 minutes. Press the **Snooze/Dimmer Button** to exit snooze setting mode.
2. Press the **Snooze/Dimmer Button** after an alarm sounds. The alarm will be silenced for the set snooze duration time then sound again. Snooze can be pressed several times during the 1 hour alarm cycle.

Sure Alarm

The unit has a sure alarm feature. If back-up batteries are installed, the buzzer alarm will still sound in the event of a power failure.

Tip: Download the free iHome Sleep app for advanced alarm, snooze and sleep functions

Charging your iPad/iPhone/Pod

1. Gently dock your iPad, iPhone or iPod. While an iPad/iPhone/iPod is docked in the unit and the unit is connected to AC power, it recharges (until fully charged). NOTE: iPod Classic (1G and 2G) will not charge.

Listening to iPad/iPhone/iPod

1. Dock the already playing iPad/iPhone/iPod in Dock. The unit will automatically turn on and you will hear the music playing from your iPhone/iPod.
Note: If the playing song volume is too low on the iPad/iPhone/iPod, the unit may not detect iPod is in play mode. Press the **▶|| Button** to play it.
2. When an iPhone/iPod is docked and in standby mode, press the **▶|| Button** to play it. “iPod” will appear on the display to indicate iPod playing mode.
4. Press the **▶|| Button** again to pause play; press again to resume it.
5. Press the **+** or **- Button** to skip to the next or previous track on your iPad/iPhone/iPod. Press and hold the **+** or **- Button** to search within a track.
6. Press the **⏮** or **⏭** to adjust the system volume.
7. Press the **EQ Button** as needed to select Treble, Bass, Balance or 3D Sound, then press the **+** or **- Button** to adjust settings .
8. To turn off the unit, press the **⏻ Button**. An iPad/iPhone/iPod will continue charging while docked.

Listening to Radio

Setting up Antenna

Extend FM wire antenna fully for best reception. Do not strip, alter or attach to other antennas.

Tuning and Playing the Radio

1. Press the **Mode Button** as needed to turn on the unit and cycle through iPod, FM radio and Line-in modes.
2. When the FM mode is selected, press the **+** or **- Button** to tune the radio to a desired station. The current radio frequency appears in the lower right of the display. Press the **+** or **- Button** for a few seconds to scan for the next clear station.

Using the unit

3. You can set up to 6 **presets**. *To memorize a station as a preset:*

- A. Press and release the **Mode Button** to select the FM band.
- B. Press and release the **Preset Button** as needed to step through the 6 presets (P1 - P6) to the number you wish to assign, and then hold the **Preset Button** until the selected preset number begins flashing in the display.
- C. Press and release the **+ or - Button** to tune the radio to a desired station. Hold briefly to have the radio autoscans/search for the next clear station.
- D. Press and release the **Preset Button** to confirm the setting. A confirmation beep will confirm the setting and the preset number you wish to assign. Repeat steps A-D to preset up to 6 stations.

4. To listen to a preset station, press the **Mode Button** to select the desired FM band. Then press and release the **Preset Button** as needed to choose the desired preset.

5. Press and release the **⏮ or ⏭ Button** to adjust the system volume. If desired, adjust the EQ as described under Listening to iPad/iPhone/iPod.

6. To turn off the radio (and the unit), press and release the **⏻ Button**.

TIP: Download the iHome Radio app from the App Store to enjoy thousands of internet radio stations from around the globe on your unit.

Using the Aux-in Jack

You can play any portable audio device with a standard 3.5 mm headphone jack through the unit via the Line-in Jack.

1. Plug one end of a standard audio patch cord (not included) into the headphone or line-out jack on your device and the other end of the patch cord into the unit Aux-in Jack located on the back of the unit.
2. Press and release the **Mode Button** until "Aux-in" appears in the lower part of the display.
3. Turn on and play your device.
4. Press and release the **⏮ or ⏭ Button** to adjust the system volume. You may need to adjust the volume on your external device as well.
5. Press and release the **EQ Button** as needed to select Treble, Bass, Balance or 3D Sound, then press and release the **+ or - Button** to adjust settings.
6. To turn off the unit, press and release the **⏻ Button**. Please remember to turn off your device, too.

Sleep Operation

Sleep mode lets you sleep to your iPhone/Pod or radio, gradually lowering the volume until the unit shuts off at the selected time.

1. Press and release the **Bedtime Button** to enter sleep mode. The sleep time will show in the lower display.
2. Press and release the **Bedtime Button** again as needed to adjust the sleep timer from 120, 90, 60, 30, 15 minutes or OFF.
3. When the display changes back to show the real time, press and release the **Sleep Button** once to show the sleep time remaining. Pressing it again will change sleep time to next lowest increment.
4. The unit has an independent volume setting for sleep mode so you can adjust the sleeping volume without affecting the normal volume. Press and release the **⏮ or ⏭ Button** to adjust the sleep volume. The sleep volume will remain at that level the next time you enter sleep mode until controls are changed.
5. To stop listening at any time, press and release the **⏻ Button** to turn unit off.

Using the unit

Nap Operation

Nap mode lets you set an alarm separate from the Alarm 1 and Alarm 2 settings. The nap wake to source by default is the buzzer alarm, but if an iPad/iPhone/iPod is docked, that will act as the alarm source. If you are listening to the radio or aux-in source, it will be muted and the buzzer will sound at the selected wake time.

1. Press and release the **Nap Button** located on top of the unit as needed to adjust the nap timer for 5, 10, 15, 20, 30, 45, 60, 90 or 120 minutes or OFF.
2. To cancel nap mode, press and release the **Nap Button** until OFF is displayed. To turn off the nap alarm once it sounds, press the **⏏ Button**.

Dimmer Operation

During normal operation (when no alarm is sounding), press and release the **Snooze/Dimmer Button** to control the brightness of the LCD display.

Using the unit in Other Countries

Different regions of the world use different FM radio frequency steps and ranges. You will need to select the one that matches the standards in your region (USA, EUROPE, JAPAN, AUSTRALIA, or CHINA). The default setting is USA; if you live in the US, you may skip this section.

1. Make sure the unit is OFF (not playing in any mode). Press and hold the **Mode Button** for about 5 seconds until “Radio xxx” appears in the lower part of display. Press the **+** or **- Button** to set the “xxx” to your region.
2. Press and release the **Mode Button** again (or no button within 5 seconds) to exit the radio frequency setting mode.


Installing/Replacing Clock Back-up Batteries

We recommend the use of alkaline batteries for longer life.

The unit comes with 2 AA back-up batteries installed to provide continuous alarm operation and clock settings in the event of a power failure. When the Battery Low Icon located on the right of the display is flashing, it is time to replace the back-up batteries.

1. Open the battery compartment cover located on the bottom of the unit.
2. Please make sure the AC adaptor is connected, otherwise all settings may be lost during battery replacement.
3. Insert 2 AA batteries, checking that the polarity (+ and – ends of the battery) matches the drawing near the battery compartment. Close the compartment door.

Note: Make sure you dispose of batteries properly (see your local regulations).



Battery Warning

For models that require more than one battery

- Do not mix with used or other battery types/brands
- Replace all batteries at the same time
- Do not open batteries
- Do not dispose of in fire
- Do not heat above 75°C (167°F)
- Do not expose contents to water
- Do not charge or recharge
- Do not install backwards

IMPORTANT SAFETY INSTRUCTIONS

When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in these instructions and on the unit.

1. **Water and Moisture** – The unit should not be used near water. For example: near a bathtub, washbowl, kitchen sink, laundry tub, swimming pool or in a wet basement.
2. **Ventilation** – The unit should be situated so that its location or position does not interfere with its proper ventilation. For example, it should not be situated on a bed, sofa, rug or similar surface that may block ventilation openings. Also, it should not be placed in a built-in installation, such as a bookcase or cabinet, which may impede the flow of air through the ventilation openings.
3. **Heat** – The unit should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.
4. **Power Sources** – The unit should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.
5. **Power-Cable Protection** – Power supply cables should be routed so that they are not likely to be walked on or pinched by items placed upon or against them. It is always best to have a clear area from where the cable exits the unit to where it is plugged into an AC socket.
6. **Cleaning** – The unit should be cleaned only as recommended. See the Maintenance section of this manual for cleaning instructions.
7. **Objects and Liquid Entry** – Care should be taken so that objects do not fall and liquids are not spilled into any openings or vents located on the product.
8. **Attachments** – Do not use attachments not recommended by the product manufacturer.
9. **Lightning and Power Surge Protection** – Unplug the unit from the wall socket and disconnect the antenna or cable system during a lightning storm or when it is left unattended and unused for long periods of time. This will prevent damage to the product due to lightning and power-line surges.
10. **Overloading** – Do not overload wall sockets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
11. **Damage Requiring Service** – The unit should be serviced by qualified service personnel when:
 - A. the power supply cable or plug has been damaged.
 - B. objects have fallen into or liquid has been spilled into the enclosure.
 - C. the unit has been exposed to rain.
 - D. the unit has been dropped or the enclosure damaged.
 - E. the unit exhibits a marked change in performance or does not operate normally.
12. **Antenna** – Do not connect an external antenna to the unit (other than that provided).
13. **Periods of Nonuse** – If the unit is to be left unused for an extended period of time, such as a month or longer, the power cable should be unplugged from the unit to prevent damage or corrosion.
14. **Servicing** – The user should not attempt to service the unit beyond those methods described in the user's operating instructions. Service methods not covered in the operating instructions should be referred to qualified service personnel.

Questions? Visit www.ihomeaudio.com

Troubleshooting

Symptom	Possible Problem	Solution
Unit does not turn on	AC adaptor isn't plugged into a working wall socket or not plugged into the power supply jack on back of the unit	Plug the AC adaptor into a working wall socket and plug the connector into the supply jack on the unit
Unit doesn't respond	Unit requires a reset	If unit is plugged in and doesn't respond, try resetting the unit by following these steps: a) remove iPad/iPhone/iPod from dock b) unplug unit from power source c) remove back up batteries d) wait a few minutes, replace batteries, plug in, then resume use
	iPad/iPhone/iPod is not docked properly	Remove your iPad/iPhone/iPod from the dock and check for obstruction on the connectors in the dock and on your iPad/iPhone/iPod. Then reseal it in the dock.
Battery Low icon always flashing	Batteries are weak	Replace with new batteries
	Batteries were not installed properly	Check to make sure the polarity (+ and – ends) matches the diagram in the battery compartment
iPad/iPhone/iPod does not respond to the unit/iPod is playing but no sound comes out	iPad/iPhone/iPod is not docked properly	Remove your iPad/iPhone/iPod from the dock and check for obstruction on the connectors in the dock and on your iPad/iPhone/iPod. Then reseal it in the dock.
	Your iPad/iPhone/iPod software is too old	Upgrade software on your iPad/iPhone/iPod via iTunes on your computer
	iPad/iPhone/iPod is locked up/plays but no sound comes out	Check the volume setting. Make sure your iPad/iPhone/iPod is working properly before docking into the unit. Please refer to your iPad/iPhone/iPod manual for details. See above for software upgrade information. You may need to reset your iPad/iPhone/iPod. Refer to your iPad, iPhone or iPod user guide for details on how to perform a reset.
	Using 1 st or 2 nd generation iPod, iPod Shuffle or other devices.	This system cannot control those iPod models or other devices.
Unit/iPad/iPhone/iPod performance is erratic	The unit is reacting to external interference	Move unit away from potential sources of external interference such as computers, modems, wireless devices (routers) or fluorescent light.
No sound from unit	Volume is set too low on unit	Make sure volume is turned up
iPad/iPhone/iPod didn't charge up	iPad/iPhone/iPod is not installed properly	Remove your iPad/iPhone/iPod from the dock and check for obstruction on the connectors in the dock and on your iPad/iPhone/iPod. Then reseal it in the dock.
	iPad/iPhone/iPod is locked up/ frozen	Please make sure your iPad/iPhone/iPod is working properly before docking into the unit. Please refer to your iPad/iPhone/iPod manual for details.
	iPad/iPhone/iPod battery has problem	
Time sync didn't work	Older iPod models such as iPod mini do not support time sync function	Make sure you are using a properly docked iPad, iPhone or newer iPod such as touch, nano or classic. If not available, set time manually (see page 4).

Troubleshooting

Symptom	Possible Problem	Solution
Sound is distorted	Volume level is set too high	Decrease the volume
	Sound source is distorted	If the iPad/iPhone/iPod original sound source is old or of poor quality, distortion and noise are easily noticed with high-power speakers. Try a different audio file from a trusted source such as iTunes.
		If you are using an external sound source try reducing the output volume on the device itself. Also try turning bass boost OFF.
	EQ settings are too high. For example, if the treble is too high, the 3D effect may not sound as good	Lower EQ settings.
Unit/adaptor gets warm after extended play at high volume	This is normal	Turn unit off for awhile or lower volume
Snooze time is too long/short	Custom snooze time not set	Press and hold Snooze button then press + or - button to adjust
Alarm not working	AM/PM time/alarm time not set correctly	When setting clock or alarm time, take note of the AM/PM indicators
	Alarm time or source selected for alarm 2 , not alarm 1 or vice versa	Make sure to set the alarm time and source for the alarm icon 1 or 2 that is shown on the clock display
	Alarm schedule setting is not correct	Full week = 7 days, weekdays = 5 days (Mon-Fri), and weekends= 2 days (Sat-Sun). See page 5 for setting alarms.
	Calendar is not set correctly, which can affect 7/5/2 day alarm operation	See page 4 for setting Clock/Calendar Section.

Limited 1 Year Warranty Information

iHome Products, a division of SDI Technologies Inc. (hereafter referred to as SDI Technologies), warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for a period of 1 Year from the date of original purchase.

Should this product fail to function in a satisfactory manner, it is best to first return it to the store where it was originally purchased. Should this fail to resolve the matter and service still be required by reason of any defect or malfunction during the warranty period, SDI Technologies will repair or, at its discretion, replace this product without charge (except for a \$15.00 charge for handling, packing, return UPS/postage, and insurance). This decision is subject to verification of the defect or malfunction upon delivery of this product to the Factory Service Center listed below. The product must include proof of purchase, including date of purchase. The fee for service without proof of purchase is \$40.00.

Before returning this product for service, please first replace the batteries (if applicable) with fresh ones, as exhausted or defective batteries are the most common cause of problems encountered.

If service is still required:

1. Remove the batteries (if applicable) and pack the unit in a well padded, heavy corrugated box.
2. Enclose a photocopy of your sales receipt, credit card statement, or other proof of the date of purchase, if within the warranty period.
3. Enclose a check or money order payable to the order of SDI Technologies, for the sum of \$15.00 (\$40.00 without proof of purchase).
4. Send the unit prepaid and insured, to the Factory Service Center listed below.

Consumer Repair Department

SDI Technologies Inc.
1330 Goodyear Dr.
El Paso, TX 79936-6420

Disclaimer of Warranty

NOTE: This warranty is valid only if the product is used for the purpose for which it was designed. It does not cover (i) products which have been damaged by negligence or willful actions, misuse or accident, or which have been modified or repaired by unauthorized persons; (ii) cracked or broken cabinets, or units damaged by excessive heat; (iii) damage to digital media players, CD's or tape cassettes (if applicable); (iv) the cost of shipping this product to the Factory Service Center and its return to the owner.

This warranty is valid only in the United States of America and does not extend to owners of the product other than to the original purchaser. In no event will SDI Technologies or any of its affiliates, contractors, resellers, their officers, directors, shareholders, members or agents be liable to you or any third party for any consequential or incidental damages, any lost profits, actual, exemplary or punitive damages. (Some states do not allow limitations on implied warranties or exclusion of consequential damages, so these restrictions may not apply to you.) This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Your acknowledgment and agreement to fully and completely abide by the above mentioned disclaimer of warranty is contractually binding to you upon your transfer of currency (money order, cashier's check, or credit card) for purchase of your SDI Technologies product.

Questions? Visit www.ihomeaudio.com
Toll Free Customer Service: 1-877-446-6301
©SDI Technologies 2011 All rights Reserved.