



## THE AIR

BLUETOOTH/WIFI HOME SPEAKER SYSTEM  
WITH WIRELESS CHARGING + ALEXA VOICE CONTROL

Model: CAVS

## WHAT'S IN THE BOX:

- The Air (CAVS-19)
- 5V/2A Power Adapter

## WHAT YOU'LL NEED:

- WiFi network broadcasting at 2.4GHz
- Apple device running iOS 10 or later or Android device running Lollipop 5.0 or later connected to your preferred WiFi network
- Install the Cavalier app and Amazon Alexa app (iOS or Android) for setup and to enable Alexa voice control and WiFi streaming music services

Questions? www.cavalieraudio.com 1-800-925-6226

3

## SETUP OVERVIEW

- Plug included AC adapter into the DC Jack on back of unit. Connect other end of cable into a working wall outlet.



- Download the Cavalier Audio app from the App Store or Google Play.
- Download the Amazon Alexa app from the App Store or Google Play.
- Follow Cavalier Audio in-app instructions for account setup and to establish your speaker's WiFi connection.
- Connect your Amazon account to enjoy the Alexa voice capability of your CAVS.



Works better together  
ALEXA  
CAVALIER AUDIO  
THE AIR



Use the Amazon Alexa app to  
enable voice control  
connect your device  
to the speaker

2



## USING THE AMAZON ALEXA APP WITH THE AIR

- Open the Amazon Alexa app on your device to activate, name, and manage Amazon Voice Services
- Link WiFi streaming music services (such as Pandora, TuneIn, iHeartRadio, Spotify, and Amazon Music)
- Enable your favorite Alexa Skills
- Setup compatible Smart Home devices

## LISTEN OUT LOUD WITH SPOTIFY CONNECT

- Connect your Air to your WiFi network
- Open up the Spotify app on your phone, tablet or laptop using the same WiFi network
- Play a song and select Devices Available
- Select your Air and start listening

The Spotify Software is subject to third party license found here: <https://open.spotify.com/licenses>

3

## TOP CONTROLS



### Bluetooth Button

- Press to enter Bluetooth Mode
- Press and hold for 2 seconds to enter Bluetooth Pairing Mode
- Press Cavalier Air to pair
- Press and hold for 10 seconds to disconnect Bluetooth

### Mute Button

- Press to mute and unmute mix (enables privacy for Alexa)

### Smart Button

- Play/Pause = 1 Press
- Forward = 2 Press
- Reverse = 3 Press
- Alexa = Press + Hold
- Answer Call = 1 Press
- End Call = Press + Hold
- Ignore Call = Press + Hold

### AIR Alarm Button\*

- Press and hold for set alarm
- Press + or - to adjust alarm time
- Press alarm button again to confirm
- Press + or - to choose AM or PM
- Press alarm button again to confirm
- Press + or - to choose radio to source Bluetooth (BT) or Home town (SD)
- If you choose SD, press alarm button again to confirm
- If you choose SD, press + or - to choose alarm, then press the alarm button again to confirm
- Press + or - to adjust the alarm volume
- Press alarm button again to confirm all alarm settings
- When alarm is armed, the button will glow red
- When alarm sounds, press to turn OFF

\*The AIR alarm does not require Alexa to be active. Set up advanced alarm scheduling via the Cavalier Audio app.

4

## REAR CONTROLS



### USB Charging Port

- When unit is connected to AC power, connect USB cable (not included) to charge device

### DC Jack

- When unit is connected to AC power, connect USB cable (not included) to charge device

### Clock Display

- Press to cycle through display brightness: Low, High, A.U.A. (Auto) and OFF
- Press and hold for 10 seconds to select 12/24 hour display format (Use + or - to confirm)
- Press Display again to confirm
- Press + or - to adjust clock
- Press Display again to confirm
- Press + or - to select AM or PM
- Press Display again to confirm settings

### WiFi

- Press for WiFi mode
- Press and hold for 5 seconds for WiFi setup mode
- Press and hold for 10 seconds to disconnect WiFi and Alexa

### Note: This is the fastest, most reliable method for charging your devices.

5

## WIRELESS CHARGING



### Qi Compatible Phones:

The device will wirelessly charge Qi compatible wireless charging phones. PMA wireless charging system is not supported.

### Qi Compatible Phone Cases:

**WARNING:** Remove metal protection or magnetic case from phone before charging. When charging phone, do not place magnetic striped or other metal objects on the charger. Doing so could damage the object or this unit. Qi compatible phones with metallic looking finishes will charge normally.

6

## WIRELESS CHARGING



### How to Charge Your Phone:

Center Qi compatible device face-up on marked charging target circle. The LED status indicators will glow orange while your device charges, and green when your device is fully charged.

### Playing Music During Qi Charging:

The volume level will be limited during Qi charging. If you prefer to listen to music at a high-volume level while charging your device, we recommend using the built-in USB port on the back of the unit.

**Notes:** The charging phone may shift position while music is playing. Please use caution. The wireless charging process generates heat that may cause phones and chargers to get warm to the touch. This is normal for wireless charging devices.

7

## ALEXA VOICE-ACTIVATED ALARMS



In addition to the AIR alarm function on the CAVS, you can also set alarms using Alexa voice commands.

### Alexa Tune Alarms


- Ask Alexa to set your alarm time. You will wake to custom Alexa tones that can be customized using the Alexa app.
- When the alarm sounds:
  - Press the alarm button or say, "Alexa, stop" to disable.
  - Hit the Snooze button on the CAVS, or say "Alexa, snooze" to activate Snooze.

### Alexa Music/Streaming Alarms

- Ask Alexa to set your alarm time to wake to Spotify, iHeart Radio, etc.
- When the alarm sounds:
  - Press the Smart Button or say, "Alexa, stop" to disable.
  - Say "Alexa, snooze" to activate Snooze.

8

## STATUS LEDS



- White indicators display volume level
- Red = mix muted
- When mix is muted, the center LED will display status.

### Bluetooth/WiFi Indicator

- Flashing blue = pairing
- Solid blue = paired
- Flashing orange = WiFi setup/No Connection
- LED OFF = WiFi Connected

### Qi Charging

- Solid orange = charging
- Solid green = device is fully charged
- Flashing red = charging error

9

## FCC Information

### FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

This device complies with Part 15 of the FCC Rules, operations subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- NOTES:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
  - Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.

CAN ICES-1 (B)/NMB-1 (B), CAN/ESR-216 / CNR-216

10

## Model: CAVS

### FCC ID:MBCAVS

### IC:NB8-CAVS

## Canada Statement

This device complies with Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions:

- This device may not cause interference; and
- This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- L'appareil ne doit pas produire de brouillage
- L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure condition without restriction.

Le dispositif a été évalué à satisfaire l'exigence générale de l'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.

**Important:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTES:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAN ICES-1 (B)/NMB-1 (B), CAN/ESR-216 / CNR-216

11

## Internal Rechargeable Lithium-ion Battery

This unit features an internal, non-replaceable backup battery for the alarm. If you experience a temporary power outage, the backup battery will maintain your time and alarm settings until AC power is restored.

### WARNING/DISPOSAL OF UNIT

Do NOT attempt to change the battery. Doing so will void the warranty and could cause injury and damage to your device. To dispose of the unit, follow the instructions below:

- Never dispose of used batteries/electronics with ordinary solid waste, since they may contain toxic substances.
- Always dispose of used batteries/electronics in accordance with the prevailing community regulations.
- Many electronics retailers now recycle batteries and other electronic components at no charge.

### GENERAL BATTERY PRECAUTIONS

- Never use or charge a battery if it appears to be leaking, discolored, deformed, or in any way abnormal.
- Never disassemble the unit or attempt to remove battery as that could cause leakage of alkaline solution or other electrolytic substances.
- Avoid charging a rechargeable battery when the temperature is not within 5°C - 35°C (41°F - 95°F) above zero.
- Never expose a battery to any liquid.
- Never expose a battery to direct sunlight or fire. Never use a battery pack in an unventilated vehicle where excessive internal temperatures may be encountered.
- Always keep batteries out of the reach of infants and small children.

12

## IMPORTANT SAFETY INSTRUCTIONS

Please read all warning, read and follow all instructions and keep these instructions handy for future reference.

- Do not use this product near water and clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Heat - This product should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this product during lightning storms or when unused for long periods of time.
- Damage Return/Service - This product should be serviced by qualified service personnel when:
  - Plug has been damaged.
  - Objects have fallen into or liquid has been spilled into the enclosure.
  - The unit has been dropped or the enclosure damaged.
  - The unit exhibits marked change in performance or does not operate normally.
- No rated flame sources, such as incandescent candles, should be placed on this product.
- This product is suitable for use in tropical and/or moderate climates.
- WARNING:** To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.
- The main plug of power adapter is used as the disconnect device, it shall remain readily operable.

13