




**Model: iB85**  
**Bluetooth wireless**  
**headphones with mic**  
**+ remote and pouch**



## **Introduction**

Your new iHome Bluetooth stereo headphones are designed to link with your Bluetooth enabled device to allow you to wirelessly listen to music and answer phone calls within the normal 10 meter (30 feet) Bluetooth operating range. Your headphones also feature DSP (Digital Signal Processing) for enhanced audio plus noise reduction and echo cancellation circuitry.


## **What's Included**

- Bluetooth Stereo Headphones with Folding Headband
- USB Charging Cable
- Travel Pouch

## **Specifications**

Bluetooth specification:	Supports V2.1+ EDR with Handsfree Profile 1.0, Headset Profile 1.1 and A2DP profile 1.2 (Class II) and Audio/Video Remote Control Profile AVRP
Standby time:	up to 360 hours (with fully charged battery)
Talk time:	up to 12 hours (with fully charged battery)
Music Playing time:	up to 12 hours (with fully charged battery)
Operating Distance:	up to 10 meters / 30 feet
Certifications:	CE, FCC, RoHS, BQB


## Controls and Indicators



1. Multi-function button: Power On/Off, Answer/End, Play/Pause, Pair
2. Power/Charging/Pairing Indicator
3. Volume + button
4. Volume - button
5. Microphone
6. Forward button <<
7. Back button >>
8. Micro USB Charging Port  
(located under moisture resistant cover)

## Charging Your Headphones

**IMPORTANT:** Your headphones operate on a built-in rechargeable lithium-ion battery. You should charge the battery for a full 4 hours before first time use.



1. Lift up the moisture resistant cover to expose the micro USB charging port.
2. Connect the micro USB plug on the charging cable to the micro USB port on the headphones.
3. Connect the standard USB plug on the charging cable to any standard USB power port such as found on a notebook computer, or the charging adapter for an iPod, iPhone, etc.
4. The headphone will be automatically powered off once USB cable is connected. Throughout the charging process, headphone remains off.
5. The Power/Charging/Pairing indicator will slowly flash while the headphone is charging. The indicator will turn Off when the battery is fully charged. It is recommended not to leave the headphones charging for more than 5 hours unattended.

**Reminder:** Allow the battery to charge for 4 hours before first time use. Normal recharge time after first use should take about 3 hours. When fully charged the battery will provide up to 12 hours of working time, or 360 hours of standby time.

## **Pairing With a Bluetooth Enabled Device For The First Time**

If your smartphone, laptop, or music player, such as the iPod touch, is Bluetooth enabled (supports the A2DP Bluetooth Profile) you may pair these iHome headphones with your device to listen to music and make or receive calls as long as the two devices are within the Bluetooth operating range of approximately 30 feet of each other.

1. Make sure that your Bluetooth enabled device is 'On'.
2. Press and hold the Multi-function button on your iB85 headphone for about 7 seconds until the blue LED flashes rapidly. This indicates that the iB85 has entered the 'pairing mode'. (NOTE: If no device is paired within 3 minutes, the iB85 will exit the pairing mode.)
3. Turn on the Bluetooth function of your device so that it begins searching for a compatible device.
4. "iHome iB85" should appear on your laptop, phone or music player's compatible devices list. You may also see a message such as "Not Paired". Tap on that message to complete the pairing process. If your device asks for a 'password' to complete the pairing process, enter '0000' on the keypad of your device.
5. When pairing is successful the screen on your device should show "iHome iB85 Connected" or similar message and the blue LED indicator on the iB85 headphones will remain 'On'. Your headphones are now ready for use.

## **Auto-Linking With A Previously Paired Device**

If your iB85 headphones were previously paired with a Bluetooth enabled device, your headphones will attempt to auto-link with that device again whenever that device is within the Bluetooth operating range.

1. Press and hold the Multi-function button on your iB85 headphones for about 4 seconds until the blue LED indicator slowly flashes to indicate the headphones are in the 'Standby' mode and searching for a previously paired device.
2. Make sure that the Bluetooth function of the previously paired device is 'On'.

Note: If no previously paired device is found after 5 minutes the auto-linking function stops and your iB85 headphones shut off automatically to preserve the battery life.

## **Switching the Power On and Off**

1. Press and hold the Multi-function button for approximately 4 seconds until you hear the power up tone. The LED indicator turns solid blue if linked or blinking blue if not linked. This indicates that the power is 'On'.
2. When the power is 'On' press and hold the Multi-function button for approximately 3 seconds until you hear the power down tone. The LED indicator briefly turns red and then shuts off. This indicates that the power is 'Off'.

## **Wearing Your Headphones**

Your iHome iB85 Bluetooth headphones are supplied with padded ear cushions for long wearing comfort. The headband can be extended to accommodate almost any head size. There are 'L' and 'R' markings on the inside of the headband. When the headphones are worn properly the controls will be on your left ear.

## **Using Your Headphones**

Note: Some of the functions described below may not be supported on your specific smartphone. Check with your smartphone owner's manual to confirm the features supported by your phone.

Your headphones must be paired with your phone and turned on to perform any of the following operations.

### **Receiving/Ending A Call**

When you receive an incoming call, press the Multi-function button once to answer the call through the headphones. When you are finished speaking press the Multi-function button once more to end/disconnect the call.

To transfer a call between the headphones and the smartphone quickly press the Multi-function button twice.

### **Making A Call**

When you make a call on your smartphone the call may be automatically transferred to the headphones if your smartphone supports this automatic transfer function. If not, quickly press the Multi-function button twice to transfer the call to the headphones.

### **Voice Activated Calling**

If your smartphone supports this feature with the headphones, press and hold the Multi-function button for about 2 seconds to initiate the voice activated calling function, then follow the instructions supplied with your phone.

### **Last Number Redial**

If your phone supports this feature, quickly press the Multi-function button twice to redial the last number you called.

### **Declining A Call**

If you receive a call that you would rather not accept (indicated by the caller ID on your phone) quickly press the Multi-function button twice to decline the call.

### **Volume Control**

Press the Volume " + " or " - " to adjust the volume of the incoming calls or the music volume level.

## Listening to Music

To listen to music your headphones must be paired and connected to a laptop, smartphone or music player that supports the A2DP Bluetooth profile (see “Pairing With a Bluetooth Enabled Smartphone or Music Player” above). To play music, use the playback controls on the connected device. If you answer or make a call while listening to music, the music will pause automatically until you end the call.

You may also use the buttons on the ‘L’ earpiece to control the music as follows:

**Play or Pause** – Press the Multi-function button once to start playback; press again to pause; press once more to resume playback.

**Track Controls** – Press the ►► button during playback to go to previous track. Press the ◀◀ button during playback to go to next track.

**Volume Controls** – Press the “+” or “-” buttons to control the music playback volume.

## Troubleshooting

<b>Reception is noisy or intermittent</b>	Make sure that the headphones and the paired device are within the Bluetooth operating range of approximately 30-feet.
<b>No Sound</b>	Make sure that your headphones are properly paired and connected with your Bluetooth enabled smartphone or music player. Refer to the “Pairing” instructions in this manual and in the manual supplied with device if necessary.
	The rechargeable battery in your headphones may be exhausted and need to be recharged. Refer to the “Charging Your Headphones” instructions in this manual.
<b>Unable to Pair/Connect</b>	The pairing settings between the headphones and your smartphone or music player may have been erased or deleted. Follow the “Pairing” instructions in this manual to repair and reconnect the devices.
	Turn off any other Bluetooth devices that are not being used to reduce external interference.
<b>Some Functions Do Not Work</b>	Your specific model of smartphone may not support some of the functions described in this manual. Refer to the manual supplied with your phone for further information.

## Care and Maintenance

Always remember to turn your headphones off if they will not be used for a long period of time. Do not expose your headphones to extremely hot or cold temperatures for extended periods. Do not expose them to direct sunlight or leave them in places such as the dashboard of your car on a hot day. Prevent water or any other liquids from entering the cabinets of your headphones.

## Protect Your Hearing

Using these, or any headphones at high volume levels for long periods can result in permanent hearing damage. Always start listening with volume controls on your headphones and your paired device at a low level and then gradually increase the volume controls to a comfortable listening level.

## Important Notes

It is dangerous and illegal (in some jurisdictions) to use headphones when you are driving a car, riding a bike or motorcycle, or operating a watercraft. Be aware of local laws and regulations.

Do not use these headphones in situations where they might cause distractions or prevent you from hearing warning sounds.

There are no user serviceable parts in these headphones. Do not attempt any service or repairs on your own. Refer to the warranty for service, repair or replacement information.

**FCC Radiation Exposure Statement**

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

This Device complies with RSS-210 of the IC Rules; Operation is subject to the following two conditions:

- (1) This device may not cause interference and
- (2) This device must accept any interference received, including interference that may cause undesired operation

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

**This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.**

- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This Class B digital apparatus complies with Canadian ICES-003.

**Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.**

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio RSS-210. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

## Limited One-Year Warranty Information

---

iHome Products, a division of SDI Technologies Inc. (hereafter referred to as SDI), warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for one year of the product from the date of original purchase.

Should this product fail to function in a satisfactory manner, it is best to first return it to the store where it was originally purchased. Should this fail to resolve the matter and service still be required by reason of any defect or malfunction during the warranty period, SDI will repair or, at its discretion, replace this product without charge. This decision is subject to verification of the defect or malfunction upon delivery of this product to the Factory Service Center authorized by SDI Customer Service. The product must include proof of purchase, including date of purchase. An out-of-warranty fee for service will be charged for units that are received without proof of purchase.

Before returning this product for service, please first replace the batteries (if applicable) with fresh ones, as exhausted or defective batteries are the most common cause of problems encountered.

If service is still required:

1. Call SDI Customer Service at 1-800-288-2792 for Return Authorization and for the address of the Factory Service Center.
2. Remove the batteries (if applicable) and pack the unit in a well padded, heavy corrugated box. SDI is not responsible for damage that occurs during shipping to the Factory Service Center.
3. Enclose a photocopy of your sales receipt, credit card statement, or other proof of the date of purchase, if within the warranty period. Also include your name and address information, a brief description for why the unit is being returned, and the return authorization number. No unit can be processed without a return authorization number.
4. Write the return authorization number on the side of the shipping package and send the unit prepaid and insured to the Factory Service Center address authorized by SDI Customer Service.

### Disclaimer of Warranty

NOTE: This warranty is valid only if the product is used for the purpose for which it was designed. It does not cover (i) products which have been damaged by negligence or willful actions, misuse or accident, or which have been modified or repaired by unauthorized persons; (ii) cracked or broken cabinets, or units damaged by excessive heat; (iii) damage to digital media players, CD's or tape cassettes (if applicable); (iv) the cost of shipping this product to the Factory Service Center and its return to the owner.

This warranty is valid only in the United States of America and does not extend to owners of the product other than to the original purchaser. In no event will SDI or any of its affiliates, contractors, resellers, their officers, directors, shareholders, members or agents be liable to you or any third party for any consequential or incidental damages, any lost profits, actual, exemplary or punitive damages. (Some states do not allow limitations on implied warranties or exclusion of consequential damages, so these restrictions may not apply to you.) This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Your acknowledgement and agreement to fully and completely abide by the above mentioned disclaimer of warranty is contractually binding to you upon your transfer of currency (money order, cashier's check, or credit card) for purchase of your SDI product.

© 2013 SDI Technologies, Inc. All rights reserved

**Questions? Visit [www.ihome.com](http://www.ihome.com) or call 1-800-288-2792 Toll Free.**