





Model: iZ44

Soothing Sound and Light Machine

QUESTIONS? visit www.ihome.com



WELCOME


Thank you for choosing the iZ44 Soothing Sound and Light Machine from iHome. For more information about this and other iHome products, please visit www.ihome.com

GETTING STARTED

This unit ships with the following items. Please check to see that all items are present.

1. i744 speaker

2. USB Charging Cable





2. USB Charging Cable

MAINTENANCE


1. iZ44 speaker

- Place the unit on a level surface away from sources of direct sunlight or excessive heat.
- Protect your furniture when placing your unit on a natural wood and lacquered finish. A cloth or other protective material should be placed between it and the furniture. • Clean your unit with a soft cloth moistened only with mild soap
- and water. Stronger cleaning agents such as thinner or similar materials can damage the surface of the unit.


This product is not a medical device and and is not intended to diagnose, treat, cure, or prevent any disease.

FEATURES & FUNCTIONS

BOTTOM PANEL




BACK PANEL



CHARGING THE IZ44

Connect the small plug of the included USB charging cable to the USB port on the back of the unit. Connect the other end to a powered USB port.







POWER ON/OFF

Press the Power Button to turn the unit ON or OFF. Note: The last sound and/or light modes will automatically save when the unit is powered OFF.

LED INDICATORS

Charging LED:

Fast flash red = battery low When connected to USB:

Solid red = charging

LED off = fully charged

RESET

In the event of interrupted operation, use the extended tip of a paper clip or other thin tool to press in the Reset button.

SOOTHING SOUND MODES

Sound Therapy uses specially recorded and engineered sounds to allow your baby to relax. Press any one of three **Soothing** Sound Buttons (Lullaby, White Noise or Nature) to access Soothing Sound modes. Press and release the button repeatedly to cycle to each mode.

LULLABY

Brahms: Classical music has a soothing and calming effect **Silent Night**: An instrumental version of the classic song Twinkle: An instrumental version of the classic song

WHITE NOISE

Air: Brown noise is a low-toned repeating frequency, like a fan Focus: Pink noise is a medium-toned repeating frequency, like a

Quiet: The standard white noise repeating frequency, like radio

NATURE (Authentic, Digitally Recorded Nature Sounds) Nature: Springtime woodland sounds Ocean: Waves crashing on a beach **Storm**: Subtle thunder and strong rainfall

OFF:

Press and hold any of the Soothing Sound buttons (Lullaby, White Noise, or Nature) to turn off the preset sounds.

SOUND TIMER

When any Soothing Sound Mode is active, press the Sound Timer Button as needed to cycle to the desired timer duration: 10 minutes, 30 minutes, 1 hour, and OFF.

Press and hold the Sound Timer Button for 2 seconds to cancel timer mode.

LIGHT MODES

Press the Light Mode Button repeatedly to cycle through 4 light modes:

- Middle
- Low Off



LIGHT TIMER

When Light Mode is active, press the Light Timer Button as needed to cycle to the desired timer duration: 10 minutes, 30 minutes, 1 hour, and OFF.

Press and hold the Light Timer Button for 2 seconds to cancel timer mode.

INTERNAL RECHARGEABLE LITHIUM-ION BATTERY

This device uses an internal rechargeable lithium-ion battery that should last the lifetime of the device. If you suspect your battery may be dead, try charging it several times.

WARNING/DISPOSAL OF UNIT

- Do NOT attempt to change the battery. Doing so will void the warranty and could cause injury and damage to your device. To dispose of the unit, follow the instructions below:

 Never dispose of used batteries/electronics with ordinary solid wastes, since they may contain toxic substances
- Always dispose of used batteries/electronics in accordance with the prevailing community
- Many electronics retailers now recycle batteries and other electronic components at no charge. To find a drop-off location near you, visit www.call2recycle.com

GENERAL BATTERY PRECAUTIONS

- Never use or charge a battery if it appears to be leaking, discolored, deformed, or in any way
- Never disassemble the unit or attempt to remove battery as that could cause leakage of alkaline solution or other electrolytic substances.
- Avoid charging a rechargeable battery when the temperature is not within 5°C 35° C (41° 95° Fahrenheit).
- Never expose a battery to any liquid.

 Never expose a battery to excessive heat such as direct sunlight or fire. Never use a battery pack in an unventilated vehicle where excessive internal temperatures may be encountered.

Always keep batteries out of the reach of infants and small children.

IMPORTANT SAFETY INSTRUCTIONS

ease heed all warnings, read and follow all instructions and keep these instructions handy for future reference. Unplug unit and clean only with damp cloth. Stronger cleaning agents, such as Benzene,

- thinner or similar materials can damage the surface of the unit. Do not block any ventilation openings. Install in accordance with the manufacturer's
- 3. Heat This product should be situated away from heat sources such as radiators, heat
- Heat This product should be studed away from heat sources sources sources registers, stoves or other appliances (including amplifiers) that produce heat.
 Only use attachments/accessories specified by the manufacturer.
- Unplug this product during lightning storms or when unused for long periods of time.
 Damage Requiring Service This product should be serviced by qualified service personnel
- Objects have fallen into or liquid has been spilled into the enclosure. The unit has been exposed to rain. The unit has been dropped or the enclosure damaged.
 The unit exhibits a marked change in performance or does not operate normally.
- No naked flame sources, such as lighted candles, should be placed on this product.

Attention should be drawn to the environmental aspects of battery disposal. This product is suitable for use in tropical and/or moderate climates. WARNING:

- reduce the risk of fire or electric shock, do not expose this product to rain or moisture Do not dispose of batteries in the household trash or fire.
- The mains plug of power adaptor is used as the disconnect device, it shall remain readily
- If the unit is to be unused for an extended period of time, such as a month or longer, charge the unit fully before storage.

 Always use a UL/ETL certified charging adapter (not included), and the supplied USB

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

 Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device.

pursuant to Part 15 of the FCC Rules.
hese limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in

accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment

- Reorient or relocate the receiving antenna. · Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 Consult the dealer or an experienced radio/TV technician for help.

ISED Information

CAN ICES-3(B) / NMB-3(B)

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the

The device comply with ISED RF exposure requirement, users can obtain Canadian information on RF exposure

Any Changes or modifications not expressly approved by the party responsible for compliance could void the

user's authority to operate the equipment. Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnement

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes

(1) L'appareil ne doit pas produire de brouillage;
(2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

L'appareil est conforme aux exigences d'exposition RF ISED, les utilisateurs peuvent obtenir des informations canadiennes sur l'exposition aux RF et la conformité. Tout changement ou modification non expressément approuvé par la partie responsable de la conformité peut annuler l'autorité de l'utilisateur à utiliser l'équipement.

WARRANTY

For product support information and warranty please visit: www.ihome.com/support © 2021 SDI Technologies, Inc. All rights reserved Questions? Visit www.ihome.com

iZ44-051221-A(EN) Printed in China

4

5