




Model: NB467

Sport Ear Buds with Modular Cord System




Using Your New Balance Sport Ear Buds with Foldable Behind The Neck Band

Your New Balance Ear Buds feature a foldable neckband for compact storage. Unfold the neckband completely, place it behind your neck with the short cord on your left side and insert the ear buds into your ears.


Your New Balance Sport Ear Buds were designed with a modular cord system. We have provided a 15" cable that is suitable if your music player will be worn in an arm-band or clipped to your clothing at chest level. We have also provided a 36" cable that is suitable if your music player will be clipped to your belt, placed in your pocket or carried in a fanny-pack

Connect the male headphone plug of the ear buds to the female headphone jack of either the 15" or 36" headphone cable depending on your wearing preference. Then connect the male headphone plug of the 15" or 36" cable to the headphone jack of your music player. Be sure that the plugs are fully inserted into the jacks. If the plug is not fully inserted you may only hear sound from one earpiece.



Using the Accessory Cord Winder Clip


Your New Balance Ear Buds are also supplied with a cord winder clip that may be used to eliminate excess slack in the 36" cable if necessary. If you find that the 36" cable is too long you can store up to 24" of cable in the cord winder and then clip the cord winder to your clothing.



Using the Water Resistant Connection Cover

Your New Balance Ear Buds are also supplied with a silicon sleeve that can be used to cover the connection between the male headphone plug on the Ear Buds and the female headphone jack on the 15" or 36" cable. Use this connection cover if you routinely use your Ear Buds in extremely wet or damp conditions.

Stretch the connection cover over the plug of the Ear Buds as shown. After connecting the male plug of the Ear Buds to the female jack on the 15" or 36" cable. Slide the connection cover down so that it completely covers the plug and jack connection point to seal out excess moisture.



Safety Information

To protect your hearing, always start listening with the Volume Control of your music player set to a low level and gradually increase the volume to a comfortable listening level.

IMPORTANT! Listening at high volume for long periods of time can result in long-term hearing damage. For your safety, do not use headphones if they would prevent you from hearing warning sounds, such as while driving a car or motorcycle, riding a bike, etc.

NOTE: In extremely cold or dry air conditions you may notice a slight ‘tingling’ feeling in your ears when using in-ear headphones. This is the result of the build-up of static electricity in your body. This is normal and not an indication of any problem with your headphones.